

IAR80 QUICK REFERENCE
for more info check WWW.FLIGHTGEAR.ORG



- | | | |
|----------------------|------------------------------|-----------------------------------|
| 1. LIGHT SW | 9. MAGNETIC COMPASS | 17. CLOCK |
| 2. PROP PITCH IND | 10. AIRSPEED IND (KPH) | 18. VOLTMETER |
| 3. OIL/FUEL PRESSURE | 11. TURN-SLIP IND | 19. GEAR PRESSURE GAUGE |
| 4. OIL TEMPERATURE | 12. VERTICAL SPEED IND | 20. FLAPS PRESSURE GAUGE |
| 5. BOOST PRESSURE | 13. AUTOMATIC FIRE EXT. IND. | 21. PUMP PRESSURE GAUGE |
| 6. RPM GAUGE | 14. LIGHT SWITCH | 22. COMPRESSED AIR PRESSURE GAUGE |
| 7. GEAR POSITION IND | 15. STARTER SWITCH | 23. BRAKES PRESSURE GAUGE |
| 8. ALTITUDE IND | 16. FUEL GAUGE (LITRES) | |

IAR80 QUICK REFERENCE
for more info check WWW.FLIGHTGEAR.ORG



1. MAGNETOS SW
2. GEAR EMERGENCY RELEASE
3. GUNS MASTER ARM
4. MG'S MASTER ARM
5. FLAPS LEVER
6. GEAR LEVER
7. PROP PITCH SELECTOR
8. MIXTURE LEVER

9. THROTTLE LEVER

IAR80 QUICK REFERENCE
for more info check WWW.FLIGHTGEAR.ORG



1. GEAR SAFETY KNOB
2. MANUAL PUMP
3. CHAIR ADJUST LEVER
4. COWL FLAPS CONTROL LEVER
5. POSITION-LIGHTS SWITCH
6. ELECTRICAL MASTER SWITCH
7. PRIMER